

## Rødt blinkende lys Alarmvarslingen er aktivert



Området skal evakueres, men du har mulighet til å avstille varslingen en kort tid for å sjekke mulig branntilløp/røykutvikling i området



Trykk 1 sekund



Oransje blinkende lys

- Sjekk mulig branntilløp/røykutvikling i området
- Ved et reelt og ukontrollerbart branntilløp, evakuer straks
- Dersom det ikke er et branntilløp og du klarer å stanse en røykutvikling, foreta en grundig utslufting

## Kort grønt blink – normaltilstand

Dersom du skal gjøre noe som kan føre til røykutvikling (for eks. matlaging med stekeos), kan du forhåndsavstille alarmvarsling (lyd/lys) i 30 minutter



Trykk 5 sekunder



Oransje blinkende lys



## **Red pulsing light An alarm is activated**



An evacuation is to be carried out, but you have the possibility to turn off the alarm for a short period in order to investigate the area for a possible fire outbreak/smoke development



**Press 1 second**



**Orange pulsing light**

- Investigate the area for a possible fire outbreak/smoke development
- If a real and uncontrollable fire outbreak has occurred, *evacuate the premises immediately*
- If there is no fire outbreak and you manage to stop a smoke development, ventilate the room with fresh air



## **Short green pulse – normal status**

If you intend to perform activities which likely may cause smoke development (for example, oven cooking which may cause smoke) you can in advance turn off the alarm (audio/visual) for 30 minutes



**Press 5 seconds**



**Orange pulsing light**